

# CASS COUNTY P.L.S. CORNER

## POINT NUMBERING SYSTEM

(SECTION LINE POINTS ALWAYS REFER TO THE SECTION SOUTH AND WEST OF THE LINE)


**TWP 1## = DIGIT 1 AND 2 (LAST TWO DIGITS OF THE TWP)**

**RGE ## = 2ND TWO DIGITS (TWO DIGITS OF RANGE)**

### LAST TWO DIGITS KEY

#### 1/4 - 1/4 GRID LOCATION IN SECTION

(8TH AND 9TH DIGIT)




### SEVENTH DIGIT KEY

#### APPROX. INCREMENTS NORTH/EAST ALONG A 1/4-1/4 SECTION LINE

7TH DIGIT # = (FRACTIONAL TENTHS EAST ALONG A STANDARD 1/4-1/4 SECTION)

# = 7TH DIGIT  
8TH & 9TH DIGITS



(EQUIVALENT CHAINS NORTH/EAST ALONG A STANDARD 1/4-1/4 SECTION)